


Burroughs

MATT ORSIE



**SERIES B 700
HANDBOOK**

CONSOLE INDICATOR LOCATION AND DATA WORDS



* "ON" INDICATOR GOES ON WHEN POWER IS APPLIED TO CONSOLE

	CONTROL								DATA							
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
MIR	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
IND "S" DATA WORD	1	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0
IND "D" DATA WORD	1	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0
IND "C" DATA WORD	1	0	0	0	0	1	0	0	PK24	PK23	PK22	PK21	PK20	PK19	PK18	PK17
IND "R" DATA WORD	1	0	0	0	1	0	0	0	PK16	PK15	PK14	PK13	PK12	PK11	PK10	PK9
IND "A" DATA WORD	1	0	0	1	0	0	0	0	PK8	PK7	PK6	PK5	PK4	PK3 or UTIL	PK2 or LOAD	PK1 or START

CONSOLE KEYBOARD CODES, ASCII

Keyboard Symbol	Keyboard Code	Keyboard Symbol	Keyboard Code	Keyboard Symbol	Keyboard Code
0	0001 0000	Space	0011 0000	A	0101 0001
1	0001 0001		0011 0010	B	0101 0010
2	0001 0010		0011 0011	C	0101 0011
3	0001 0011		0011 0100	D	0101 0100
4	0001 0100	OKC I	0011 0101	E	0101 0101
5	0001 0101		0011 0110	F	0101 0110
6	0001 0110	OKC II	0011 0111	G	0101 0111
7	0001 0111		0011 1000	H	0101 1000
8	0001 1000		0011 1001	I	0101 1001
9	0001 1001		0011 1010	J	0101 1010
	0001 1010		0011 1011	K	0101 1011
	0001 1011		0011 1100	L	0101 1100
	0001 1100		0011 1101	M	0101 1101
	0001 1101		0011 1110	N	0101 1110
	0001 1110		0011 1111	O	0101 1111
	0001 1111				
RESET	0010 0000	P	0100 0000	PK18	0110 0000
	0010 0001	Q	0100 0001	PK19	0110 0001
	0010 0010	R	0100 0010	PK20	0110 0010
	0010 0011	S	0100 0011	PK21	0110 0011
	0010 0100	T	0100 0100		
	0010 0101	U	0100 0101		
	0010 0110	V	0100 0110		
	0010 0111	W	0100 0111		
	0010 1000	X	0100 1000		
	0010 1001	Y	0100 1001		
	0010 1010	Z	0100 1010		
	0010 1011		0100 1011		
	0010 1100	OKC III	0100 1100	PK17	0110 1100
	0010 1101		0100 1101	PK22	0110 1101
	0010 1110	OKC IV	0100 1110	PK23	0110 1110
	0010 1111	OKC V	0100 1111	PK24	0110 1111

SEE NOTES 1, 2 NEXT PAGE

CONSOLE KEYBOARD CODES, ASCII (CONT)

Keyboard Symbol	Keyboard Code	Keyboard Symbol	Keyboard Code
PK01	0111 0000		1011 0000
PK02	0111 0001		1011 0001
PK03	0111 0010		1011 0010
PK04	0111 0011		1011 0011
PK05	0111 0100		1011 0100
PK06	0111 0101	O C K █ █ █	1011 0101
PK07	0111 0110	O C K █ █ █	1011 0110
PK08	0111 0111		1011 0111
PK09	0111 1000	+	1011 1000
PK10	0111 1001	=	1011 1001
PK11	0111 1010	<	1011 1010
PK12	0111 1011	>	1011 1011
PK13	0111 1100	*	1011 1100
PK14	0111 1101	[1011 1101
PK15	0111 1110	?	1011 1110
PK16	0111 1111	^	1011 1111

NOTES:

- Only these codes are valid when loading micro/nano memories from numeric keyboard or memory loader unit. All other codes will be ignored.
- All 256 code combinations are valid when loading data/program memory (DPM) from memory loader unit.
- When the "shift" key is depressed the left most bit of the keyboard code will be "1".

RIGHT

↑
↓
1
1
1001 1111

CONSOLE PRINTER CHARACTER SET, ASCII

Print Char.	Printer Code	Print Char.	Printer Code	Print Char.	Printer Code	Print Char.	Printer Code
~ ²	0000 0000	0	0001 0000	@	0100 0000	P	0101 0000
1	0000 0001	1	0001 0001	A	0100 0001	Q	0101 0001
"	0000 0010	2	0001 0010	B	0100 0010	R	0101 0010
#	0000 0011	3	0001 0011	C	0100 0011	S	0101 0011
\$	0000 0100	4	0001 0100	D	0100 0100	T	0101 0100
%	0000 0101	5	0001 0101	E	0100 0101	U	0101 0101
&	0000 0110	6	0001 0110	F	0100 0110	V	0101 0110
'	0000 0111	7	0001 0111	G	0100 0111	W	0101 0111
(0000 1000	8	0001 1000	H	0100 1000	X	0101 1000
)	0000 1001	9	0001 1001	I	0100 1001	Y	0101 1001
*	0000 1010	:	0001 1010	J	0100 1010	Z	0101 1010
+	0000 1011	;	0001 1011	K	0100 1011	[0101 1011
,	0000 1100	<	0001 1100	L	0100 1100	\	0101 1100
-	0000 1101	=	0001 1101	M	0100 1101	^	0101 1101
.	0000 1110	>	0001 1110	N	0100 1110	^	0101 1110
/	0000 1111	?	0001 1111	O	0100 1111	^	0101 1111

ROTATE

TILT	7	6	5	4	3	2	1	0	15	14	13	12	11	10	9	8		
0	#	"	'	&	%	\$	7	6	5	4	G	F	E	D	W	V	U	T
1	+	*)	(:	9	8	K	J	I	H	I	Z	Y	X			
2	/	.	-	,	;	>	=	<	O	N	M	L	^	^	^			
3																		

¹ ASCII code is compatible with console printer code except for "space", code 0010 0000. ASCII will print ~ (tilde).

² To "print" a space the PRINT bit of the printer data word must be zero to suppress printing and the appropriate escapement bit must be one.

INTERCHANGE CODES

PAPER TAPE CODE	USASCII			ERODIC		BCL		96-COLUMN	
	USASCII CHAR	7-BIT INT. CODE COL, ROW	L & TC GRAPHIC	GRAPHIC CHAR	CARD CODE	GRAPHIC CHAR	CARD CODE	GRAPHIC CHAR	CARD CODE
0	NULL	0,0	End of Alpha	NULL	12-0-9-8-1				
1	SOH	0,1		SOH	12-9-1				
2	STX	0,2		STX	12-9-2				
3	ETX	0,3		ETX	12-9-3				
4	EOT	0,4		EOT	9-7				
5	ENG	0,5		ENG	0-9-8-5				
6	ACK	0,6		ACK	0-9-8-6				
7	BEL	0,7		BEL	0-9-8-7				
8	BS	0,8		BS	11-9-6				
9	HT	0,9		HT	12-9-5				
10	LF	0,9		LF	0-9-5				
11	VT	0,10		VT	12-9-8-3				
12	FF	0,10		FF	12-9-8-4				
13	CR	0,10		CR	12-9-8-5				
14	SO	0,10		SO	12-9-8-6				
15	SI	0,10		SI	12-9-8-7				
16	DLE	1,0		DLE	12-11-9-8-1				
17	DC1	1,1		DC1	11-9-1				
18	DC2	1,2		DC2	11-9-2				
19	DC3	1,3		DC3	11-9-3				
20	DC4	1,4		DC4	9-8-4				
21	NAK	1,5		NAK	9-8-5				
22	SYN	1,6		SYN	9-8				
23	ETB	1,7		ETB	0-9-6				
24	CAN	1,8		CAN	11-9-8				
25	EM	1,9		EM	11-9-8-1				
26	SUB	1,9		SUB	9-8-7				
27	ESC	1,10		ESC	0-9-7				
28	FS	1,10		FS	11-9-8-4				
29	GS	1,10		GS	11-9-8-5				
30	RS	1,10		RS	11-9-8-6				
31	US	1,10		US	11-9-8-7				

INTERCHANGE CODES (CONT)

PAPER TAPE CODE	USASCII			ERODIC		BCL		96-COLUMN	
	USASCII CHAR	7-BIT INT. CODE COL, ROW	L & TC GRAPHIC	GRAPHIC CHAR	CARD CODE	GRAPHIC CHAR	CARD CODE	GRAPHIC CHAR	CARD CODE
32	SP	2,0	SP	SP	Blank	SP	Blank	SP	00 0000
33	"	2,1	"	"	11-0	"	11-0	"	10 1010
34	#	2,2	#	#	8-7	#	8-7	#	00 1111
35	\$	2,3	\$	\$	8-3	\$	8-3	\$	00 1011
36	%	2,4	%	%	11-8-3	%	11-8-3	%	10 1011
37	&	2,5	&	&	0-8-4	&	0-8-4	&	01 1100
38	'	2,6	'	'	12	'	12	'	01 1010
39	(2,7	((8-5	(8-5	(00 1101
40)	2,8))	12-8-5)	12-8-5)	11 1101
41	*	2,9	*	*	11-8-5	*	11-8-5	*	10 1101
42	+	2,10	+	+	11-8-4	+	11-8-4	+	10 1100
43	=	2,10	=	=	12-0	=	12-0	=	11 1110
44	-	2,10	-	-	0-8-3	-	0-8-3	-	00 1101
45	.	2,10	.	.	11	.	11	.	10 0000
46	/	2,10	/	/	12-8-3	/	12-8-3	/	11 1011
47	0	3,0	0	0	0-1	0	0-1	0	01 0001
48	1	3,1	1	1	0	1	0	1	01 0000
49	2	3,2	2	2	2	2	2	2	00 0001
50	3	3,3	3	3	3	3	3	3	00 0010
51	4	3,4	4	4	4	4	4	4	00 0011
52	5	3,5	5	5	5	5	5	5	00 0100
53	6	3,6	6	6	6	6	6	6	00 0101
54	7	3,7	7	7	7	7	7	7	00 0110
55	8	3,8	8	8	8	8	8	8	00 0111
56	9	3,9	9	9	9	9	9	9	00 1000
57	3,A	3,9	3,A	3,A	8-2	3,A	8-2	3,A	00 1001
58	1	3,B	1	1	11-8-6	1	11-8-6	1	00 1010
59	<	3,C	<	<	12-8-4	<	12-8-4	<	10 1110
60	=	3,D	=	=	8-6	=	8-6	=	11 1100
61	>	3,E	>	>	0-8-6	>	0-8-6	>	01 1110
62	?	3,F	?	?	0-8-7	?	0-8-7	?	01 1111

INTERCHANGE CODES (CONT)

PAPER TAPE CODE	USASCTI CHAR	USASCTI		EBCDIC		BCL		96-COLUMN		
		7-BIT INT. CODE COL, ROW	L & TC GRAPHIC	GRAPHIC CHAR	CARD CODE	8-BIT INT. CODE COL, ROW	GRAPHIC CHAR	CARD CODE	GRAPHIC CHAR	CARD CODE
P7654E321	@	4,0	A	@	8-4	7,C	@	8-4	@	00 1100
	A	4,1	B	A	12-1	C,1	A	12-1	A	11 0001
	B	4,2	C	B	12-2	C,2	B	12-2	B	11 0010
	C	4,3	D	C	12-3	C,3	C	12-3	C	11 0011
	D	4,4	E	D	12-4	C,4	D	12-4	D	11 0100
	E	4,5	F	E	12-5	C,5	E	12-5	E	11 0101
	F	4,6	G	F	12-6	C,6	F	12-6	F	11 0110
	G	4,7	H	G	12-7	C,7	G	12-7	G	11 0111
	H	4,8	I	H	12-8	C,8	H	12-8	H	11 1000
	I	4,9	J	I	12-9	C,9	I	12-9	I	11 1001
	J	4,A	K	J	11-1	D,1	J	11-1	J	10 0001
	K	4,B	L	K	11-2	D,2	K	11-2	K	10 0010
	L	4,C	M	L	11-3	D,3	L	11-3	L	10 0011
	M	4,D	N	M	11-4	D,4	M	11-4	M	10 0100
	N	4,E	O	N	11-5	D,5	N	11-5	N	10 0101
	O	4,E	P	O	11-6	D,6	O	11-6	O	10 0110
	P	5,0	Q	P	11-7	D,7	P	11-7	P	10 0111
	Q	5,1	R	Q	11-8	D,8	Q	11-8	Q	10 1000
	R	5,2	S	R	11-9	D,9	R	11-9	R	10 1001
	S	5,3	T	S	0-2	E,2	S	0-2	S	01 0010
	T	5,4	U	T	0-3	E,3	T	0-3	T	01 0011
	U	5,5	V	U	0-4	E,4	U	0-4	U	01 0100
	V	5,6	W	V	0-5	E,5	V	0-5	V	01 0101
	W	5,7	X	W	0-6	E,6	W	0-6	W	01 0110
	X	5,8	Y	X	0-7	E,7	X	0-7	X	01 0111
	Y	5,9	Z	Y	0-8	E,8	Y	0-8	Y	01 1000
	Z	5,A	[Z	0-9	E,9	Z	0-9	Z	01 1001
	[5,B	\ or 3/4	[12-8-2	F,9	[12-8-4	[11 1010
	\ or 3/4	5,C	\ or 6	\ or 3/4	11-8-7	5,F	\ or 3/4	11-8-7	\ or 3/4	11 1011
	\ or 6	5,D	\ or 0	\ or 6	12-8-2	5,G	\ or 6	12-8-2	\ or 6	10 1111
	\ or 0	5,E	\ or 0	\ or 0	12-8-5	5,H	\ or 0	12-8-5	\ or 0	10 1111
	\ or 0	5,F	\ or 0	\ or 0	0-8-5	6,I	\ or 0	0-8-2	\ or 0	01 1101

INTERCHANGE CODES (CONT)

PAPER TAPE CODE	USASCTI CHAR	USASCTI		EBCDIC		BCL		96-COLUMN		
		7-BIT INT. CODE COL, ROW	L & TC GRAPHIC	GRAPHIC CHAR*	CARD CODE	8-BIT INT. CODE COL, ROW	GRAPHIC CHAR	CARD CODE	GRAPHIC CHAR	CARD CODE
P7654E321	,	6,0	,	,	8-1	7,9	,	12-0-1	,	11 0000
	a	6,1	a	a	12-0-1	8,1	a	12-0-1	a	11 0001
	b	6,2	b	b	12-0-2	8,2	b	12-0-2	b	11 0010
	c	6,3	c	c	12-0-3	8,3	c	12-0-3	c	11 0011
	d	6,4	d	d	12-0-4	8,4	d	12-0-4	d	11 0100
	e	6,5	e	e	12-0-5	8,5	e	12-0-5	e	11 0101
	f	6,6	f	f	12-0-6	8,6	f	12-0-6	f	11 0110
	g	6,7	g	g	12-0-7	8,7	g	12-0-7	g	11 0111
	h	6,8	h	h	12-0-8	8,8	h	12-0-8	h	11 1000
	i	6,9	i	i	12-0-9	8,9	i	12-0-9	i	11 1001
	j	6,A	j	j	12-11-1	9,1	j	12-11-1	j	10 0001
	k	6,B	k	k	12-11-2	9,2	k	12-11-2	k	10 0010
	l	6,C	l	l	12-11-3	9,3	l	12-11-3	l	10 0011
	m	6,D	m	m	12-11-4	9,4	m	12-11-4	m	10 0100
	n	6,E	n	n	12-11-5	9,5	n	12-11-5	n	10 0101
	o	6,F	o	o	12-11-6	9,6	o	12-11-6	o	10 0110
	p	7,0	p	p	12-11-7	9,7	p	12-11-7	p	10 0111
	q	7,1	q	q	12-11-8	9,8	q	12-11-8	q	10 1000
	r	7,2	r	r	12-11-9	9,9	r	12-11-9	r	10 1001
	s	7,3	s	s	11-0-2	A,2	s	11-0-2	s	01 0010
	t	7,4	t	t	11-0-3	A,3	t	11-0-3	t	01 0011
	u	7,5	u	u	11-0-4	A,4	u	11-0-4	u	01 0100
	v	7,6	v	v	11-0-5	A,5	v	11-0-5	v	01 0101
	w	7,7	w	w	11-0-6	A,6	w	11-0-6	w	01 0110
	x	7,7	x	x	11-0-7	A,7	x	11-0-7	x	01 0111
	y	7,8	y	y	11-0-8	A,8	y	11-0-8	y	01 1000
	z	7,9	z	z	11-0-9	A,9	z	11-0-9	z	01 1001
	{	7,B	{	{			{		{	
		7,C								
	~	7,D	~	~			~		~	
	DEL	7,E	DEL	DELETE	12-8-7	4,F	DEL	12-8-7	DEL	11 0000
		7,F			12-9-7	0,7				11 1111

* DELIMITER character has a card code of 12-0, 9-8, 7 and an internal code of GF.

I/O DEVICE CONFIGURATION CODE DERIVATION

DIGITS 1 AND 2:	DEVICE TYPE
00	80-COLUMN CARD READER
01	96-COLUMN CARD READER
02	PAPER TAPE READER
03	PAPER TAPE PUNCH
04	85/160/250 LPM PRINTER
05	96-COLUMN CARD READER/PUNCH/PRINTER OR MULTI-PURPOSE UNIT.
06	MAGNETIC TAPE UNIT
07	MAGNETIC TAPE CASSETTE
08	ANY DISK CARTRIDGE DRIVE
09	ANY LINE PRINTER
10	80-COLUMN CARD READER/PUNCH/PRINTER
11	SINGLE LINE CONTROL
DIGIT 3:	HARDWARE PORT CONNECTION
1-7	DETERMINED ACCORDING TO DDP LOCATIONS ASSIGNED TO I/O DEVICE CONTROLS FOR PARTICULAR SYSTEM BEING CONFIGURED. <i>SLC=4/6 OR (6)7</i>
DIGIT 4:	INTERPRETER DESCRIPTOR PORT NUMBER
0 OR 1	80-COLUMN CARD DEVICE <i>SLC=0</i>
0 OR 1	96-COLUMN CARD DEVICE
0 OR 1	PAPER TAPE READER
2 OR 3	PAPER TAPE PUNCH
0 THROUGH 3	ANY DISK CARTRIDGE DRIVE
0 THROUGH 3	ANY MAGNETIC TAPE DEVICE
2	ANY LINE PRINTER
DIGIT 5:	INTERPRETER SUBSYSTEM NUMBER
0	LOW-SPEED SUBSYSTEM (A), INCLUDING: 80-COLUMN CARD READER PAPER TAPE READER PAPER TAPE PUNCH <i>SLC=1</i>
1	SUBSYSTEM (C), (INCLUDES SLC FOR RJE)
2	MID-SPEED SUBSYSTEM (D), INCLUDING: 96-COLUMN READER/PUNCH/PRINTER 80-COLUMN READER/PUNCH/PRINTER 96-COLUMN CARD READER
3	SUBSYSTEM (E) ANY MAGNETIC TAPE DEVICE

I/O DEVICE CONFIGURATION CODE DERIVATION (CONT)

DIGIT 5 (CONT)	INTERPRETER SUBSYSTEM NUMBER
4	HIGH-SPEED SUBSYSTEM (B), INCLUDING: ANY LINE PRINTER 96-COLUMN CARD READER*
5	ANY DISK CARTRIDGE DRIVE

* NOTE: USE ONLY WITH UTILITIES IDENTIFIED WITH 97 IN UTILITY NAME.

I/O DEVICES ELIGIBLE FOR TRANSLATION ALGORITHMS


DEVICE TYPE	DIGIT	ALGORITHM
MAGNETIC TAPE CASSETTE	0	NO TRANSLATION
	1	EBCDIC TRANSLATION
	2-9	ILLEGAL
PAPER TAPE READER	0	NO TRANSLATION
	1	8-BIT ASCII TRANSLATION
	2	5-BIT BAUDOT
	3-7	RESERVED
	8-9	ILLEGAL
PAPER TAPE PUNCH	0	NO TRANSLATION
	1	8-BIT ASCII TRANSLATION
	2	5-BIT BAUDOT
	3-7	RESERVED
	8-9	ILLEGAL
MAGNETIC TAPE UNIT	0	NO TRANSLATION
	1	EBCDIC TRANSLATION
	2-9	ILLEGAL
80-COLUMN CARD READER (ANY STYLE) OR 80-COLUMN CARD READER/PUNCH/PRINTER	0	ILLEGAL
	1	BCL TRANSLATION
	2	EBCDIC TRANSLATION*
	3-9	ILLEGAL

* DIGIT 1 = EBCDIC TRANS. DIGIT 2 = BCL TRANS. FOR MARK II.4 AND SUBSEQ. RELEASES.

CASSETTE TAPE FORMATS

TAPE LABEL FORMAT

FIELD POSITION	SIZE (BYTES)	CONTENTS	FIELD POSITION	SIZE (BYTES)	CONTENTS
0	1	BLANK	32	2	RESERVED. ACCESSIBLE TO USER TO DISTINGUISH BETWEEN MULTIPLE RUNS ON THE SAME DAY. CONTAINS "01" BY DEFAULT.
1	7	"LABEL"			
8	1	ZERO			
9	6	MULTIPLE IDENTIFIER (MFLD) FIELD; ZEROS IF NO MFLD	34	5	PURGE DATE: "99999"
15	1	BLANK	39	1	SENTINEL (0=END-OF-FILE; 1=END-OF-REEL) (ENDING LABEL ONLY)
16	1	ZERO	40	5	BLOCK COUNT (ENDING LABEL ONLY)
17	6	FILE IDENTIFIER (FLD); BLANK FOR SCRATCH FILES	45	7	BLOCK COUNT (ENDING LABEL ONLY)
23	1	BLANK	52	1	ZERO
24	3	REEL NUMBER	53	5	PHYSICAL TAPE NUMBER (INSERTED OPERATOR COMMAND)
27	5	CREATION DATA, "YYDDDD" (JULIAN FORMAT)	58	21	RESERVED



CASSETTE TAPE FORMATS (CONT)

DATA RECORD FORMATS

CAPACITY (FOR STANDARD LENGTH OF 280 FT.):

- APPROXIMATELY 2,450 80-COL. CARD IMAGES.
- APPROXIMATELY 20 PAGES OF PRINTER OUTPUT (60 LINES PER PAGE).

NOMINAL LENGTH: VARIABLE UP TO 256 BYTES.

RJE LENGTH: FIXED-LENGTH RECORDS OF 168 CHARACTERS EACH. A TAPE RECORD MAY CONTAIN ONE 132-CHARACTER PRINT LINE IMAGE RECORD OR TWO 80-CHARACTER CARD IMAGE RECORDS.

POSITION	SIZE (BYTES)	CONTENTS
0	2	NUMBER OF ITEMS THIS RECORD; FOR PRINT LINE IMAGE = 01.
2	2	RECORD TYPE; FOR PRINT LINE RECORD = 01.
4	2	CONTROL CHARACTER(S) FOR PRINT LINE RECORD.
6	132	DATA RECORD = 132-CHARACTER PRINT LINE IMAGE.
138	30	ALL ZEROS.

POSITION	SIZE (BYTES)	CONTENTS
0	2	NUMBER OF ITEMS THIS RECORD; FOR CARD IMAGE = 01 OR 02.
2	2	RECORD TYPE; FOR CARD IMAGE RECORD = 02.
4	2	CONTROL CHARACTER(S) FOR ITEM 1.
6	80	ITEM 1: 80-CHARACTER CARD IMAGE.
86	2	CONTROL CHARACTER(S) FOR ITEM 2.
88	80	ITEM 2: 80-CHARACTER CARD IMAGE.

CONFIGURATION CARD FORMAT (80 COLUMN) RJE

1	2	4	5	8	9	10	13	14	17	18	80
C		XX = Y		XX = Y		XX = Y					

(REPEAT XX = Y ENTRIES, AS REQUIRED.)

WHERE XX IS DEVICE TYPE AS FOLLOWS:

- XX
- | | |
|----|---------------------------|
| CR | CARD READER |
| SI | SINGLE-LINE CONTROL |
| PN | CARD PUNCH |
| C4 | CASSETTE TAPE DRIVE NO. 4 |
| C3 | CASSETTE TAPE DRIVE NO. 3 |
| C2 | CASSETTE TAPE DRIVE NO. 2 |
| C1 | CASSETTE TAPE DRIVE NO. 1 |
| SP | SUPERVISORY PRINTER (SPO) |
| LP | LINE PRINTER |


WHERE Y IS IOC (DDP) PORT NUMBER IN WHICH DEVICE XX IS LOCATED. NORMAL CONFIGURATION IS AS FOLLOWS:

Y (PORT)	XX (DEVICE)
1	CR
2	LP
3	PN
4	C3
5	C2
6	C1
7	SL
8	SP

EXAMPLES:

COL. 1	5-8	9	10-13	14-17	18-21	22	80
C	CR = 1		SP = 8				
C	SL = 7		PN = 3	CP = 2	CR = 5		
C	OL = 6						

DISK SEGMENT FORMAT



OBJECT (USER) PROGRAM CARD FORMATS (CONT)

COL. PROGRAM PARAMETER BLOCK (80 COL.) 3 CARDS, 8 L WORDS EACH

COL. 1-3	PPbn	P	SP	O	#	SPACE	P	BINDING	SOFTWARE	SUBSYSTEM REQUIREMENTS
4-5	n=1-3	A	U	B	L'S		B	INFORMATION	TRANSFER	BUF 0 BUF 2 BUF 3 BUF 4 BUF 5 INQ
6-7	R	N	C	H				PROTECTION		

(PACKED HEX)

(BCL ALPHA) FOR USER

COL. PROGRAM PARAMETER BLOCK (96 COL.) 6 CARDS, 4 L WORDS EACH

COL. 1-4	SP	PPbn	SPACE	#	φφφ	P	BINDING	SOFTWARE	BUF 0	BUF 2	BUF 3	BUF 4	BUF 5	INQ
5-6	n=1-0		#	L'S		B	INFORMATION	TRANSFER	BUF 0	BUF 2	BUF 3	BUF 4	BUF 5	INQ

(HEX)

(BCL)

(HEX)

(HEX)

(HEX)

43-44	SPM	MAIN	BIG	← COMPLETE →	DATE	UNUSED
45-46	CODE	SEGB	TYPE	(MDDY)		

(D-WORD SIZES) (HEX)

(D-WORD SIZES)

(HEX)

(HEX)

(HEX)

47-48	MC-COBOL
-------	----------

(D-WORD SIZES) (HEX)

(D-WORD SIZES)

(HEX)

(HEX)

49-50	MC-COBOL
-------	----------

(D-WORD SIZES) (HEX)

(D-WORD SIZES)

(HEX)

(HEX)

COLS 17	OR(17*18)	18	OR(19*20)	19	OR(21*22)	20	OR(23*24)	21	22	OR(27*28)
---------	-----------	----	-----------	----	-----------	----	-----------	----	----	-----------

D	U	P	8	SI7=0, DIL=1	CASSETTE	EDIT SPGC SL7=0, RPO=1	EXPAND COMPRESS	1	C
I	P	4	MT UNIT	80 COL MPU	SO20	MULTIPLY	EXP CMP, NO CNT OPT	0	N
G	P	2	80 COL RDR	96 COL RDR	E1	MULTIPLY LIT MEM	MOVE CHARACTERS	N	N
I	E	1	96 COL MPU		T		MOVE-4	P	F
T	R							F	T
								U	O
								P	R
								C	R
								H	O
								G	

OBJECT (USER) PROGRAM CARD FORMATS

PROGRAM HEADER (80-COL.)

1	7	8	9	13	14	33	34	36	37	48	49	55	56	57	61	62	64	65	66	74	75	80	
PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM
NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	
SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	
SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	
(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	(ACTUAL ENTRY)	
(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	(COMPACT HEX)	

PROGRAM HEADER (96-COL.)

1	7	8	9	13	14	52	53	56	57	96
PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM	PROGRAM
NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME	NAME
SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP
SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.	SEB. REQ.
(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)	(ACTUAL ENTRY IN BCL ALPHA)
(HEX)	(HEX)	(HEX)	(HEX)	(HEX)	(HEX)	(HEX)	(HEX)	(HEX)	(HEX)	(HEX)

COMPACT HEX CODES FOR PROGRAM HEADER CARDS

ASCII CHAR	PUNCH	ASCII CHAR	PUNCH	ASCII CHAR	PUNCH	ASCII CHAR	PUNCH	ASCII CHAR	PUNCH
A	11,1	I	11,8,1	R	11,9,2		0	0,9	
B	11,2	J	11,8,2	S	11,9,3		1	0,9,1	
C	11,3	K	11,8,3	T	11,9,4		2	0,9,2	
D	11,4	L	11,8,4	U	11,9,5		3	0,9,3	
E	11,5	M	11,8,5	V	11,9,6		4	0,9,4	
F	11,6	N	11,8,6	W	11,9,7		5	0,9,5	
G	11,7	O	11,8,7	X	11,9,8		6	0,9,6	
H	11,8	P	11,9,1	Y	11,9,8,1		7	0,9,7	
		Q	11,9,1	Z	11,9,8,2		8	0,9,8	
							9	0,9,8,1	

PROGRAM PARAMETER BLOCK 1

PARAMETER BLOCK 2

PARAMETER BLOCK 3

OBJECT

SEGMENT

END

STOP

OBJECT (USER) PROGRAM CARD FORMATS (CONT)

SEGMENT HEADER CARD (80-COL.)

1	7	8	19	20	21	22	23	24	25	48	49	55	56	57	61	62	74	75	80
SEGMENT	SP	SEG. NO.	SP	RELATIVE DISK STARTING SEGMENT	SP	SEGMENT	SP	PROGRAM NAME	SP	DATE COMPILED (MMDDYY)									

(ACTUAL ENTRY) (COMPACT HEX) (ACTUAL ENTRY) (BCL ALPHA) (BCL NUMERIC)

SEGMENT HEADER CARD (96-COL.)

1	8	9	13	14	24	25	30	31	36	37	40	41	54	55	56	57	96
SEGMENT	PROGRAM NAME	SP	DATE COMPILED	SP	RELATIVE DISK STARTING SEGMENT	SP	SEG. NO.	SP	DATE COMPILED	SP	RELATIVE DISK STARTING SEGMENT	SP	SEG. NO.	SP	DATE COMPILED	SP	

(ACTUAL ENTRY) (BCL ALPHA) (BCL ALPHA) (BCL NUMERIC) (BCL NUMERIC)

OBJECT (USER) PROGRAM CARD FORMATS (CONT)

DATA CARD (80-COL.)

1	6	7	8	9	10	11	12	13	14	15	16	17	80
PROGRAM NAME	β	β	β	β	MEM. TYPE	NO. WDS ON CARD	β	β	FIRST DATA WORD ADDR	DATA			
										(UP TO 8 PROGRAM WORDS, EACH WORD OCCUPIES EIGHT CARD COLUMNS. EACH CARD COLUMN CONTAINS BINARY VALUE FOR TWO OF THE 16 HEXA-DECIMAL DIGITS IN A WORD.)			

(BCL ALPHA) (PAR-ITY DIGIT) (DEC. 1-8) (COMP. HEX) O=USER MEM. 1=INTERPRETER MEM.

DATA CARD (96-COL.)

1	5	6	10	11	12	13	16	17	96	
NO SIGNIFICANCE	FIRST FIVE CHARACTERS OF NAME	NO WDS ON CARD	FIRST DATA WD ADDR	DATA						
(UP TO 8 PROGRAM WORDS, EACH WORD OCCUPIES EIGHT CARD COLUMNS. EACH CARD COLUMN CONTAINS BINARY VALUE FOR TWO OF THE 16 HEXA-DECIMAL DIGITS IN A WORD.)										

(DEC. 1-8) (COMP. 1-8) (HEX)

OBJECT (USER) PROGRAM CARD FORMATS (CONT)

STOP CARD (80 OR 96 COL.)




(80-COL. = ASCII PACKED HEX)
(96-COL. = BCL)
(β = BLANK)

END CARD (80-COL.)




END CARD (96-COL.)



PARAMETER CARD FORMATS RJE

PARAMETER	CARD COLUMNS	ENTRY	DEFAULT VALUE
RECEIVE RETRY LIMIT	1 THROUGH 11	RRTY = XXXXX WHERE: XXXXX IS DECIMAL VALUE LESS THAN 65536.	100
TRANSMIT RETRY LIMIT	1 THROUGH 11	TRTY = XXXXX WHERE: XXXXX IS DECIMAL VALUE LESS THAN 65536.	100
NO-RESPONSE RETRY LIMIT	1 THROUGH 11	NORSP = XXXXX WHERE: XXXXX IS DECIMAL VALUE LESS THAN 65536.	100
LINE TYPE	1 THROUGH 7	LINES = X WHERE X = MODE AS FOLLOWS: X MODE 2 ASYNCHRONOUS (LEASED) 3 ASYNCHRONOUS (SWITCHED) 4 DIRECT CONNECT 8 SYNCHRONOUS (LEASED) 9 SYNCHRONOUS (SWITCHED)	9
TRANSMIT DELAY	1 THROUGH 10	TDLAY = XXXXX WHERE: XXXXX IS DECIMAL VALUE OF DELAY IN MILLI- SECONDS (DELAY BETWEEN REQUEST-TO-SEND AND DATA TRANSMISSION).	NA
NO-RESPONSE TIME VALUE	1 THROUGH 10	NRLAY = XXXXX WHERE: XXXXX IS NO-RESPONSE VALUE IN MILLISECONDS	2.5 SECONDS
RECEIVE DELAY	1 THROUGH 10	RDLAY = XXXXX WHERE: XXXXX IS RECEIVE DELAY VALUE IN MILLISECONDS.	30 MILLISECONDS

PUNCHED PAPER TAPE COMPACT OBJECT CODE






- NOTES:
1. START CODE ALWAYS = 66
 2. START CODE IS NOT USED IN LNC GENERATION
 3. STOP CODE FROM MICRO LOAD = 4000
 4. LIGHT CHECK CODE IS USED FROM OPTICAL TAPE READER LOADER

SORT FIELD SPECIFIER CARD FORMATS

COL. NO.	FIELD NAME	TAG SORT	RECORD SORT	FULL SORT	BASIC SORT	UPDATE SORT
1-6	SORT MODE	X	X	X	X	X
7-11	MASTER FILE NAME	X	X	X	X	X
12	MASTER FILE DRIVE	X	X	X	X	X
13-17	TAG FILE NAME	X	X	X	X	X
18-22	OVERFLOW FILE NAME	X	X	X	X	X
23	ROUGH TABLE OPTION	X	X	X	X	X
24	TAG FILE DRIVE	X	X	X	X	X
25-28	MEMORY SIZE (UNUSED)	X	X	X	X	X
29-30	BLOCKING FACTOR	X	X	X	X	X
31-32	TOTAL KEY LENGTH	X	X	X	X	X
33-35	KEY #1 POSITION	X	X	X	X	X
36-37	KEY #1 LENGTH	X	X	X	X	X
38-40	KEY #2 POSITION	X	X	X	X	X
41-42	KEY #2 LENGTH	X	X	X	X	X
43-45	KEY #3 POSITION	X	X	X	X	X
46-47	KEY #3 LENGTH	X	X	X	X	X
48-50	KEY #4 POSITION	X	X	X	X	X
51-52	KEY #4 LENGTH	X	X	X	X	X
53-55	KEY #5 POSITION	X	X	X	X	X
56-57	KEY #5 LENGTH	X	X	X	X	X
58-80	AVAILABLE TO USER (FOR 80-COLUMN CARD)	X	X	X	X	X
58-96	AVAILABLE TO USER (FOR 96-COLUMN CARD)	X	X	X	X	X

NOTE: X = FIELD APPLICABLE TO SORT

MEMORY ADDRESS CONVERSION



MICROCONTROLS

HEX. CODE	M P M B I T L O C A T I O N																INSTR. TYPE	
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
0 0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	LOAD AMPCR	II
0 1	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	LOAD INCR & MPCR +1	II
1 0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	AMPCR REPLACED BY MPCR LOAD INCR & MPCR +1	II
SAR =, LIT =	1	1	0	0	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD LIT	II
LIT =	1	1	1	0	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD SAR	LOAD LIT	II
ALL OTHERS	1	1	1	1	0	0	0	0	0	0	0	0	0	0	0	0	NANO ADDRESS	I

B7NPL RESERVED WORDS

NOTE: ϕ = Unused

\oplus = This bit is not used for addressing.

Bincl
12-15 16

B = 8111 = ALL 2's
B = TTT = XFER ALL

NANOCONTROLS (CONT)

NANO BITS	ADDER OPERATION					LOGIC	SHIFT TYPE SELECTION FOR BSW			A REGISTER INPUT FROM BSW		
	28	29	30	31			32	33		34	35	36
0	0	0	0	0	X	+	Y		0	0	0	NO CHANGE
0	0	0	1	1	X	NOR	Y	X \bar{Y}	0	1	0	R RIGHT END OFF
0	0	1	0	0	X	NRI	Y	X \bar{Y}	1	0	0	L LEFT END OFF
0	0	1	1	1	X	+	Y	+1	1	1	1	C RIGHT CIRCULAR
0	1	0	0	0	X	NAN	Y	X \bar{Y}				
0	1	0	1	1	X	OAD	Y	X+(X+Y)				
0	1	1	1	0	X	XOR	Y	X \bar{Y} +XY				
0	1	1	1	1	X	NIM	Y	X \bar{Y}				
1	0	0	0	0	X	IMP	Y	X+Y				
1	0	0	1	1	X	EQV	Y	X \bar{Y} +XY				
1	0	1	0	0	X	AAD	Y	X+(XY)				
1	0	1	1	1	X	AND	Y	XY				
1	1	0	0	0	X	-	Y	-1	X+	\bar{Y}		
1	1	0	1	0	X	RIM	Y	X+ \bar{Y}				
1	1	1	0	0	X	OR	Y	X+Y				
1	1	1	1	1	X	-	Y	X+ \bar{Y} +1				

NANOCONTROLS (CONT)

NANO BITS	B REGISTER INPUT SELECT				MIR INPUT FROM BSW	AMP CR INPUT FROM BSW	MEMORY DEVICE ADDRESS INPUT					
	37	38	39	40			41	42	43	44	45	46
0	0	0	0	0	NO CHANGE	0	NO CHANGE	0	0	0	0	NO CHANGE
0	0	0	1	1	BC4 COMP 4 BIT CARRIES	1	MIR	0	1	0	1	LMAR FROM LIT
1	0	0	0	0	BAD ADDER			1	AMP CR			0
1	0	0	1	1	BC8 COMP 8 BIT CARRIES							1
1	0	1	0	0	BBA BSW* ADDER							1
1	0	1	1	1	B BSW							1
1	1	0	0	0	BEX EXTERNAL							1
1	1	0	1	0	BMI MIR							1
1	1	0	1	1	BBI BSW* EXTERNAL							1
1	1	1	0	0	BBE BSW* EXTERNAL							1
1	1	1	1	1	BBI BSW* MIR							1

NANO BITS	COUNTER INPUT			SAR INPUT		MEMORY DEVICE OPERATION				SAVE SIGN BIT	PARITY	
	46	47	48	49	50	51	52	53	54			55
-	0	0	0	NO CHANGE	0	0	0	0	0	NO CHANGE	0	DO NOT SAVE
0	0	1	1	LCTR FROM LIT	0	1	0	1	0	MRI	1	0**
1	0	1	0	CTR FROM BSW	1	0	SAR FROM BSW	0	1	MR2		1
-	1	0	0	INC +1				0	1	0	IOL	
								0	1	1	MW1	
								0	1	1	MW2	
								1	0	0	ASR	
								1	0	1	DR1	
								1	0	1	DR2	
								1	1	0	USEL	
								1	1	1	DW1	
								1	1	1	DW2	

** State of bit set so as to produce odd parity in NPN word.

NANOINSTRUCTION LIST (CONT)

ADDR.	INSTRUCTION	ADDR.	INSTRUCTION	ADDR.	INSTRUCTION
00CA	LC2R.	00ED	MIR = LIT + B.	010F	A1 = B000.
00CB	LIT EQV B.	00EE	MIR = LIT L.	0110	A1 = B111 R.
00CC	LIT - B.	00EF	MIR = Z.	0111	A1 EQV LIT.
00CD	LIT NAN B.	00F0	MIR = 0 + Z + 1.	0112	A1 EQV Z.
00CE	IMAR.	00F1	MRI A1 = A1 + 1.	0113	A1 = LIT - B.
00CF	MARL = AMPGR.	00F2	MRI A1 = A1 + 1.	0114	A1 EQV O, IF GOV SKIP.
00D0	MARL = A1.	00F3	MRI.	0115	A1 = Z.
00D1	MARL = A2.	00F4	SAR = B.	0116	A2 EQV B.
00D2	MARL = A3.	00F5	SAVE.	0117	A2 EQV LIT.
00D3	MARL = A3 + LIT.	00F6	SET GC2.	0118	A2 EQV O, IF LC2 SET LC2 SKIP.
00D4	MARL = A3 + 1.	00F7	SKIP.	0119	A2 - B.
00D5	MARL = B.	00F8	WHEN IRQ STEP.	011A	A2 - B - 1.
00D6	MARL = B + 1.	00F9	WHEN RDC BEK.	011B	A2 - LIT.
00D7	MARL = BMAR + 1.	00FA	WHEN RDC BEK, MARL = BMAR + 1.	011C	A2 RIM LIT.
00D8	MARL = LIT.	00FB	WHEN RMI MARL = BMAR + 1.	011D	A2 = A2 + AMPGR.
00D9	MARL = LIT + B.	00FC	WHEN SRQ STEP.	011E	A2 = A2 - B.
00DA	MIR = AMPGR.	00FD	WHEN URQ STEP.	011F	A2 = A2 - LIT.
00DB	MIR = A1.	00FE	Z EQV B.	0120	A2 = A2 XOR LIT.
00DC	MIR = A1 + B.	00FF	O EQV B.	0121	A2 = A2 XOR B111.
00DD	MIR = A2.	0100	AMPGR = A1 + AMPGR.	0122	A2 = A2 AND B.
00DE	MIR = A3.	0101	AMPGR = A3.	0123	A2 = A3 L.
00DF	MIR = A3 OR B.	0102	AMPGR = A2.	0124	A2 EQV Z.
00E0	MIR = A3 OR LIT.	0103	AMPGR = A2 + AMPGR.	0125	A2 = LIT C.
00E1	MIR = B.	0104	AMPGR = A3 + AMPGR.	0126	A2 = LIT AND B.
00E2	MIR = B C.	0105	AMPGR = AMPGR + 1.	0127	A2 = A2 C.
00E3	MIR = B + 1.	0106	AMPGR = LIT + B.	0128	B = A3 - 1.
00E4	MIR = B L.	0107	ASE, BMT, MARL = B, JUMP.	0129	B = A3 + 1.
00E5	MIR = B R.	0108	ASR BEK.	012A	B = A3 AND B.
00E6	MIR = B000.	0109	ASR BEK.	012B	B = A3 C.
00E7	MIR = B001.	010A	A1 - LIT - 1.	012C	B = A3 NRI B.
00E8	MIR = B111.	010B	A1 = LIT EQV B.	012D	B = A3 NRI B C.
00E9	MIR = BMAR.	010C	A1 = A1 C.	012E	B = A3 XOR B R.
00EA	MIR = LIT.	010D	A1 = A1 NIM B.	012F	B = A3 R, IF ABT SKIP.
00EB	MIR = LIT AND B.	010E	A1 = A1 OR B.	0130	B = B000 JUMP.
00EC	MIR = LIT OR B.	010E	A1 = B + 1.	0130	A3 = A3 AND B.

NANOINSTRUCTION LIST (CONT)

ADDR.	INSTRUCTION	ADDR.	INSTRUCTION	ADDR.	INSTRUCTION
0131	A3 = A3 - B.	0151	B = B001 JUMP.	0172	CSAR, B = B C.
0132	A3 = A3 NIM B.	0152	B = B100 JUMP.	0173	CSAR B04 A3 = A3 + B C.
0133	A3 = A3 AND B110.	0153	B = B101.	0174	CSAR MIR = B000.
0134	A3 = A3 - B C, IF NOT AOV SET LC1, JUMP ELSE JUMP.	0154	B = B111 R.	0175	CTR = A1.
0135	A3 = A3 - B C, IF GOV SET LC1, JUMP ELSE JUMP.	0155	B = B01T.	0176	CTR = A1, IF ABT SKIP.
0136	A3 = A3 XOR LIT.	0156	B = B700.	0177	CTR = A2 R.
0137	A3 = B110.	0157	B = B70T.	0178	CTR = A3.
0138	A3 = B111 L.	0158	B = B7T1.	0179	CTR = BMAR + 1.
0139	A3 = B111 R.	0159	B = B7TF.	017A	CTR = CTR + LIT + 1.
013A	A3 = B + 1.	015A	B = CTR.	017B	CTR EQV O.
013B	A3 = LIT NRI B.	015B	B = LIT - 1.	017C	CTR = LIT + CTR.
013C	A3 = LIT + B.	015C	B = LIT NRI B C.	017D	DLD.
013D	A3 = 0 + LIT.	015D	B = Z AAD B.	017E	DR2 BEK, BR2 = B.
013E	A3 SSC = A2 L.	015E	B = Z IMP B.	017F	IF ABT LUOP ELSE SKIP.
013F	A3 SSC = A2 R.	015F	B = Z NAN B.	0180	IF ABT RESET GC1.
0140	A3 SSC = LIT + B.	0161	B = Z NOR B.	0181	IF ABT RESET GC2.
0141	B = A1 AND B.	0162	B = 0 - B.	0182	IF AOV JUMP.
0142	B = A1 XOR B.	0163	B = 0 - B - 1.	0183	IF G01 SET LC1 SKIP.
0143	B = A2 AND B.	0164	B = 0 - LIT.	0184	IF G01 SET LC2 SKIP.
0144	B = A2 XOR B.	0165	BAD A3 = A3 + B.	0185	IF G01 STEP ELSE EXEC.
0145	B = A2 XOR B.	0166	BAD A3 = A3 + B.	0186	IF G01 STEP ELSE JUMP.
0146	B = A2 - LIT.	0167	B04 = B R.	0187	IF G01 STEP ELSE SAVE.
0147	B = A2 C.	0168	B04.	0188	IF G01 STEP ELSE WAIT.
0148	B = A3 - 1.	0169	B04 CSAR, A3 = A3 - B C.	0189	IF G01 RETN.
0149	B = A3 + 1.	016A	B04 SAR = B001.	018A	IF G01 SAVE.
014A	B = A3 AND B.	016B	B04.	018B	IF G01 WAIT.
014B	B = A3 C.	016C	B04 SAR = B001.	018C	IF IRQ, ASR, BEK, JUMP.
014C	B = A3 NRI B.	016D	B04 SAR = B001.	018D	IF IRQ, ASR, BEK, JUMP.
014D	B = A3 NRI B C.	016E	BR2 = A3 L.	018E	IF L01 A2 = A2 + 1.
014E	B = A3 XOR B R.	016F	BR2 = B.	018F	IF L01 INC.
014F	B = A3 R, IF ABT SKIP.	0170	CSAR = BIT.	0190	IF L01 SET LC1 ELSE JUMP.
0150	B = B000 JUMP.	0171	CSAR A3 = B R.	0192	IF LC2 SET LC2 ELSE JUMP.

NANOINSTRUCTION LIST (CONT)

ADDR.	INSTRUCTION	ADDR.	INSTRUCTION
0193	IF LC2 SET LC2 JUMP.	01B5	IF URQ SKIP.
0194	IF LC3 SET LC3 ELSE JUMP.	01B6	INC, B = BMAR.
0195	IF LST CALL.	01B7	INC IF COV JUMP.
0196	IF LST SET GC1.	01B8	INC, IF NOT COV SKIP ELSE STEP.
0197	IF LST SET LC2.	01B9	INC, SAVE.
0198	IF LST SET LC2 SKIP.	01BA	LIT, EQV 0.
0199	IF NOT ABT RESET GC1.	01BB	LIT TMP B.
019A	IF NOT ABT SET GC1.	01BC	MAR1 = A1 + LIT.
019B	IF NOT ABT SET LC1.	01BD	MAR1 = A2 + 1.
019C	IF NOT GC1 JUMP.	01BE	MAR1 = A2 + B.
019D	IF NOT GC1 STEP ELSE SKIP.	01BF	MAR1 = A2 + LIT.
019E	IF NOT GC2 JUMP.	01C0	MAR1 = A3 + AMPCR.
019F	IF NOT GC2 LUOP SKIP.	01C1	MAR1 = A3 - B.
01A0	IF NOT GC2 SET GC2 JUMP.	01C2	MAR1 = B R, ***** (B711) *****
01A1	IF NOT LC1 SET LC1.	01C3	MAR1 = B R, SKIP, ***** (B705) *****
01A2	IF NOT LC1 SET LC1 ELSE SKIP.	01C4	MAR1 = B001 + 1.
01A3	IF NOT LC1 SET LC1 SKIP.	01C5	MAR1 = BMAR + 1 IF NOT COV JUMP ELSE SAVE.
01A4	IF NOT LC2 SET LC2 JUMP.	01C6	MAR1 = LIT XOR BMAR.
01A5	IF NOT LC3 SET LC3 JUMP.	01C7	MIR = AMPCR + 1.
01A6	IF NOT LC3 SET LC3 SKIP.	01C8	MIR = A1 L.
01A7	IF NOT LST SET GC2 JUMP.	01C9	MIR = A2 L.
01A8	IF NOT LST SET GC2 SKIP.	01CA	MIR = A2 + B.
01A9	IF NOT LST SET GC2 JUMP.	01CB	MIR = A2 OR B.
01AA	IF NOT MST JUMP.	01CC	MIR = A2 OR LIT.
01AB	IF NOT IRQ JUMP.	01CD	MIR = A3 R.
01AC	IF NOT SRQ SKIP.	01CE	MIR = A3 L.
01AD	IF NOT URQ SKIP.	01CF	MIR = A3 AND B.
01AE	IF MST SET LC1.	01D0	MIR = A3 AND LIT.
01AF	IF SRQ THEN DW2 JUMP.	01D1	MIR = A3 + B.
01B1	IF URQ SET GC1 ELSE JUMP.	01D2	MIR = A3 - B.
01B2	IF URQ SET GC2 ELSE JUMP.	01D3	MIR = B, SAVE.
01B3	IF URQ SET LC2.	01D4	MIR = B001 + 1.
01B4		01D5	

NANOINSTRUCTION LIST (CONT)

ADDR.	INSTRUCTION	ADDR.	INSTRUCTION
01D6	MIR = NOT CTR R.	01E7	RETN.
01D7	MIR = Z + B001.	01E8	SAR = A2 R.
01D8	MIR = 0 AND Z.	01E9	SAR = A3 R.
01D9	MIR = 0 AND B000.	01EA	SAR = B L.
01DA	MIR = 0 AND Z.	01EB	SET GC1, JUMP.
01DB	MIR = 0 + Z.	01EC	WHEN RDC THEN JUMP.
01DC	MIR = 0 - Z.	01ED	WHEN RDC THEN BEX, A1 = A1 + 1, JUMP.
01DD	MIR = 0 - Z - 1.	01EE	WHEN RDC THEN BEX, A2 = A2 + 1, JUMP.
01DE	MIR B08 = A1 + B IC.	01EF	WHEN RDC BEX A3 = B.
01DF	MIR, A3 = B R.	01F0	WHEN RDC BEX CTR = B.
01E0	MIR, CTR = B.	01F1	WHEN RDC BEX, MAR1 = A1.
01E1	MIR, IF LC1 STEP.	01F2	WHEN RDC THEN BEX, MAR1 = BMAR + 1, JUMP.
01E2	MIR, INC.	01F3	WHEN RMI A1 = A1 + 1, JUMP.
01E3	MIR, MIR = B.	01F4	WHEN RMI A2 = A2 + 1, JUMP.
01E4	MIR, A2 = A2 + 1.	01F5	WHEN RMI THEN MAR1 = BMAR + 1, JUMP.
01E5	MIR, A2 = A2 + 1.	01F6	WHEN RMI THEN MAR1 = LIT.
01E6	MIR, INC, A3 = A3 XOR B. RESET GC1, SAVE.	01F7	WHEN RMI THEN MAR1 = LIT.

NANOMEMORY DECODING

TIMING AND GENERAL ACTION	N-MEMORY BITS	SPECIFIC ACTION
DURING PHASE 1	1-4 5 6 7	Condition selection Condition test (true/complement) Conditionally update command register from bits 17-50 of nanomemory Conditionally initiate actions shown below under "at end of Phase 1"
AT END OF PHASE 1	(a) Successor Determination 8-10 (b) External Operations 51-54	Microprogram address (MPAD) controls Condition adjust (local, global, interrupt interpreters) Request signals for main memory or peripheral device operations
PHASE 3	17-19 20-26 27 28-31 32-33	Adder input X select Adder input Y select Inhibit carries Adder or logic operation Dynamic conditions available for test in concurrent phase 1 Shift (right, left, circular) by amount in SAR
AT END OF PHASE 3	34-36 37-40 41 42 43 44 45-46 47-48 49-50 55	Input to A registers (A1, A2, A3) from BSW B register input source selection MIR input from BSW AMPCK input from BSW BR1 input from BSW BR2 input from BSW MAR input from BSW or LIT CTR input from LIT, BSW, or increment CTR SAR input from BSW, or complement SAR Load SSF
Destination Specification		Input clock commands

S-LEVEL INSTRUCTIONS

OP CODE	INSTRUCTION	OP CODE	INSTRUCTION	OP CODE	INSTRUCTION
00	ADD	34	CLKB	57	DIV
02	MVE	34	OFF	60	BRU
06	MVD	34	RR	61	SRJ
08	REM	34	STOP	62	BRPS
08	DATE	35	PC	63	BRC
09	LSR	37	RPOS	65	COMM
0A	INR	37	SPOS	67	SIND
0C	RST	40	MVE	68	PNS-
0D	SET	41	MVE	69	PNS+
0E	CHG	42	MVE	6A	PN
0E	CHG	43	MVE	6A	PC++
18	NK	43	MVE	6B	PC++
19	NKR	44	MVE	6C	TK
1A	IA	45	ADD	6D	POS
1B	SK	46	SUB	70	LGA LIT
1B	SKC	46	MVE	71	SKC LEA LIT
1D	LAT	47	COMM	72	SKC LIA LIT
1F	LP	48	ADD	72	SKC LIA LIT
1F	SKID	49	ADD	73	SKC LIA LIT
28	AL	49	ADD	74	SKC AS F
29	AR	4A	ADD	74	SKC AS F
2A	ALTO	4B	ADD	75	SKC AS F
2B	ARTO	4C	SUB	76	SKC ANS F
2C	ALR	4C	SUB	76	SKC ANS F
2D	OT	4D	SUB	77	SKC ANS F
2E	SVN	4E	SUB	78	SKC ENS F
2E	SVN	4E	SUB	78	SKC ENS F
2E	SVC	4F	SUB	78	SKC ENS F
30	SRR	50	CONV	7C	DUMP
30	PKA	50	CONV	7C	TRAC
31	PKA	51	CONV	7C	TRAC
31	PKB	52	IATA	7C	TRAC
32	PKC	52	COMM	7C	TRAC
32	PKC	53	COMM	7D	SETB
33	ALRM	54	MUL	7E	RSTB
34	CT	55	DIV	7E	LOAD
34	CT	56	MUL	7F	LOAD
				7F	ZIP

S-LEVEL INSTRUCTIONS (CONT)

OP CODE	INSTRUCTION	OP CODE	INSTRUCTION	OP CODE	INSTRUCTION
80	BRC LGA LIT	C1	EXPD	E7	SRCH
81	BRC LBA LIT	C3	SPRD	E8	ADD
82	BRC LLA LIT	C4	MVE	E9	ADD
83	BRC LLA LIT	C5	MVE	EA	SUB
84	BRC AS F	C6	SRCH	EB	SUB
85	BRC ES F	C7	SRCH	EC	MVE
86	BRC ANS F	C8	SEA EQ	ED	MVE
87	BRC ENS F	C9	SEA LS	EE	MUL
88	ADD	CA	SEA LS	EO	MUL
89	SUB	CB	MVE	F1	ADD
8A	MVE	CC	MVE	F2	ADD
8B	COM	CD	MVE	F3	ADD
8C	MVE	CE	MVE	F4	SUB
90	NK	CF	MVE	F5	SUB
91	NKR	CG	COMN	F6	SUB
94	EAM	CH	COM	F7	SUB
97	PA	D1	COMN	F8	SUB
9F	SCAN	D2	COMN	F9	BRBS
A2	MAK	D3	COMN	FB	BRBN
A4	BRU	D4	ADDB	FC	MVCH
A5	EDIT	D6	SUBB	FD	SRJS
AB	LOGL	D7	M	FE	MVSB
AE	CDC	D8	PNS+	FF	MVSB
AF	CDV	D9	PN	FE	MVBS
BO	RETM	E0	MV4	FE	MVBS
B1	LODM	E1	CMCH	FE	READ/WRIT
B2	LATM	E2	CLST	FE	READ/WRIT
B3	LATM	E3	TKM	FE	DAC
CO	CPRS	E4	EXCH	FE	TBRU
		E5	M		
		E6	H		

DISK SYSTEM COLD START ERRORS

HEXADECIMAL "DP" INDICATORS	SPO STATUS	C = CONSOLE S = SPO B = BOTH	PRINTED MESSAGE	DESCRIPTION OF ERROR
FF	TOP - BOT		(S) CD PTY	80-COLUMN CARD LRC ERROR (CSTRT 80 PROGRAM)
FF	-			CASSETTE TAPE PREAMBLE CHARACTER MISSING (CSTRT-TC PROGRAM)
XX	-			DDP STATUS WORD BITS (9 THROUGH 16) (CSTRT-TC OR CSTRT-MT)

DISK PRIMER COLD START ERRORS

80 OR 81	0 0 1	(B)	"TROUBLE" 0001 MPM PARITY-MPCR-MPM-OS	CORE MEMORY PARITY ERROR IN MICRO PROGRAM AREA.
80 OR 82	0 1 0	(B)	"TROUBLE" 0002 DPM PARITY REG. VAL.	REG. VAL. CORE MEMORY PARITY ERROR OUTSIDE MICRO PROGRAM AREA.
80 OR 83	0 1 1	(B)	"TROUBLE" 0003 NPM PARITY REG. VAL.	NANO MEMORY PARITY ERROR OR OUTSIDE NANO LIMIT.
80 OR 84	1 0 0	(B)	"TROUBLE" 0004 ADDR LIMIT REG. VAL.	CORE MEMORY ADDRESS ABOVE LIMITS.

DISK SYSTEM ERROR MESSAGES AND OPERATOR RECOVERY

DISK PRIMER COLD START (DPCS) ERRORS

ERROR PRINTOUT	PROBABLE CAUSE	OPERATOR ACTION
ADDR DISK ERROR ***	A. BAD SECTOR ON DISK CARTRIDGE. OPERATE-COMPARER SUCCESSFUL BUT RETURNED ADDRESS INCORRECT. B. ILLEGAL TRACK ADDRESS.	A. INITIALIZE CARTRIDGE. B. THIS ERROR USUALLY INDICATES A FIRMWARE OR HARDWARE MALFUNCTION.
CD PRTY ERROR ***	80-COLUMN DATA CARD HAS FAILED LRC PARITY CHECK.	IF OPERATOR DESIRES TO IGNORE ERROR (FOR EXAMPLE, CARD HAS BEEN HAND-PUNCHED) PRESS PK1 TO CONTINUE. TO RETRY FAULTY CARD, REPLACE CARD IN INPUT HOPPER AND PRESS PK8. OTHERWISE, PRESS SYSTEM-CLEAR AND TRY ANOTHER DECK, STARTING AT LAST HEADER CARD TO HAVE BEEN READ.
COPY DISK ERROR ***	A TRACK WITHIN PROTECTED SPACE ON BOTTOM CARTRIDGE HAS BAD SEGMENT.	A. RE-INITIALIZE BOTTOM CARTRIDGE. B. TRY ANOTHER CARTRIDGE.
DATA CD ERROR ***	ADDRESS ON DATA CARD JUST READ IS LOWER THAN ADDRESS FIELD OF LAST PRECEDING HEADER CARD. IF USING CASSETTE OR MAGNETIC TAPE, TAPE IS BAD. AN "END" CARD MAY BE MISSING FROM DECK.	TRY ANOTHER DECK, CASSETTE, OR TAPE REEL.
DIRECTORY ERROR ***	NO PROTECTED DIRECTORY SPACE AVAILABLE FOR THIS LOAD.	THIS AND SUBSEQUENT LOADS REQUIRING DIRECTORY ENTRIES MUST BE MADE AFTER WARM START WITH S-LEVEL CARD LOADER UTILITY.
DVCE DISK ERROR ***	STATUS ERROR IN DISK UNIT WHICH FIRMWARE DOES NOT RECOGNIZE. DISK UNIT, PROCESSOR, OR FIRMWARE ERROR.	TECHNICAL ASSISTANCE REQUIRED.
DVCE TAPE ERROR ***	SAME AS "DVCE DISK ERROR", BUT REFERS TO CASSETTE DRIVE OR MAGNETIC TAPE UNIT.	CHECK THAT TAPE DRIVE IS OPERATIONAL.

DISK SYSTEM ERROR MESSAGES AND OPERATOR RECOVERY (CONT)

DISK PRIMER COLD START (DPCS) ERRORS (CONT)

ERROR PRINTOUT	PROBABLE CAUSE	OPERATOR ACTION
FILE DISK ERROR ***	A. DISK UNIT NOT OPERATIONAL. B. WRITE LOCKOUT ON DISK DRIVE. C. CABLE CONNECTOR TO DISK UNIT NOT PROPERLY SEATED.	A. READY UNIT. B. ENABLE WRITE ON CARTRIDGE. C. ENSURE PROPER CONNECTION TO DISK UNIT.
FILE TAPE ERROR ***	CASSETTE DRIVE OR MAGNETIC TAPE UNIT NOT OPERATIONAL.	READY UNIT.
HDR CRD ERROR ***	LOAD PHASE DID NOT FIND VALID HEADER CARD WHEN ONE WAS EXPECTED. EITHER HEADER CARD IS ERRONEOUS, OR DECK IS SCRAMBLED. IF USING CASSETTE OR MAGNETIC TAPE, TAPE IS INCORRECT.	A. CORRECT DECK AND RETRY LOAD. B. TRY ANOTHER CARTRIDGE OR TAPE REEL.
INIT DISK ERROR ***	MORE THAN 50 BAD SEGMENTS OR 9 BAD AREAS HAVE BEEN FOUND WHILE INITIALIZING THIS DISK CARTRIDGE. THIS CONDITION MAY ALSO BE CAUSED BY A MALFUNCTIONING DISK DRIVE. CAUTION: ABOVE ERROR CONDITION MAY INDICATE SERIOUS MISALIGNMENT OF CARTRIDGE. DO NOT ATTEMPT MORE THAN ONE RETRY WITH THE SAME CARTRIDGE, OTHERWISE READ/WRITE HEADS MAY BE DAMAGED.	A. RETRY INITIALIZATION. B. TRY ANOTHER CARTRIDGE. C. CHECK FOR PROPER FUNCTIONING OF DISK UNIT.
LOAD DISK ERROR ***	CAN OCCUR DURING LOAD OR COPY PHASES IF ANY TRACK WITHIN PROTECTED SPACE ON TOP DISK CARTRIDGE HAS A BAD SEGMENT.	A. REINITIALIZE TOP CARTRIDGE. B. USE ANOTHER CARTRIDGE.
PRTY DISK ERROR ***	DURING ANY PHASE OF DPCS OPERATION, INDICATES AN LRC READ ERROR ON TOP CARTRIDGE.	A RETRY OF THE OPERATION MAY BE SUCCESSFUL, HOWEVER, A TRUE LRC ERROR MEANS THAT CARTRIDGE IS NO LONGER USABLE AND MUST BE INITIALIZED. ALL DATA ON CARTRIDGE WILL BE LOST. FIRST DETERMINE THAT DISK UNIT IS OPERATING PROPERLY BEFORE ATTEMPTING RETRY.

DISK SYSTEM ERROR MESSAGES AND OPERATOR RECOVERY (CONT)

DISK PRIMER COLD START (DPCS) ERRORS (CONT)

ERROR PRINTOUT	PROBABLE CAUSE	OPERATOR ACTION
PRTY TAPE ERROR ***	TAPE CASSETTE OR MAGNETIC TAPE RECORD HAS FAILED CYCLIC REDUNDANCY CHECK FOR DATA VALIDITY.	A. RETRY LOAD. B. TRY ANOTHER CASSETTE OR TAPE REEL.
SEEK DISK ERROR ***	SEEK ERROR ON DISK UNIT.	TECHNICAL ASSISTANCE REQUIRED.
SERV TAPE ERROR ***	SERVICE LATE ON DISK READ OR WRITE. DISK UNIT, PROCESSOR, OR FIRMWARE ERROR.	"DPCS" SOURCE MAY BE FAULTY; TRY AGAIN.
SERV TAPE ERROR ***	SERVICE LATE ON MAGNETIC TAPE OR CASSETTE READ OPERATION. TAPE DRIVE, PROCESSOR, OR FIRMWARE ERROR.	SAME AS "SERV DISK ERROR".
SPACE ERROR ***	NO PROTECTED DISK SPACE REMAINS FOR THIS LOAD.	IF THIS AND SUBSEQUENT LOADS MUST BE TO PROTECTED SPACE, THEN INITIALIZATION OF DISK AND COMPLETE COLD START IS REQUIRED. IF USING CARD INPUTS, SOME PROGRAMS MAY HAVE TO BE OMITTED FROM COLD START AND LOADED AFTER WARM START WITH S-LEVEL CARD LOADER UTILITY.
TAPE ERROR ***	A. CASSETTE RECORD IS MISSING A POSTAMBLE OR PREAMBLE CHARACTER. B. END OF TAPE REACHED WITHOUT FINDING "STOP" CARD IMAGE.	RETRY LOAD WITH THIS CASSETTE, OR TRY ANOTHER CASSETTE OR TAPE REEL.
TIME DISK ERROR ***	INSTRUCTION TIMEOUT ON DISK UNIT. CAN BE CAUSED BY HARDWARE MALFUNCTION OR BAD CARTRIDGE SECTOR ADDRESS.	A. DISK CARTRIDGE MAY REQUIRE INITIALIZATION. B. SYSTEM CLEAR BUTTON SHOULD BE PRESSED.

DISK SYSTEM WARM START (WSTRT) ERRORS (CONSOLE INDICATIONS)

HEX. "D" INDICATOR PATTERN	PROBABLE CAUSE	OPERATOR RESPONSE
01	MPM PARITY ERROR	TECHNICAL ASSISTANCE REQUIRED
02	DPM PARITY ERROR	TECHNICAL ASSISTANCE REQUIRED
03	NPM PARITY ERROR	TECHNICAL ASSISTANCE REQUIRED FIRMWARE CARTRIDGE MAY BE BAD.
04	ADDRESS LIMIT ERROR	FIRMWARE CARTRIDGE MAY BE BAD. TECHNICAL ASSISTANCE REQUIRED.
06	ERRONEOUS I/O ALGORITHM NUMBER	DEPRESS "RESET" KEY; RE-DO WARM-START USING CORRECT INFORMATION.
07	MEMORY SIZE ERROR	DEPRESS "RESET" KEY; REENTER CORRECT SIZE.
08	DISK UNIT NOT OPERATIONAL	READY UNIT. RECOVERY IS AUTOMATIC IF UNIT IS FUNCTIONING. ENSURE THAT CORRECT IOC/DDP NUMBER WAS ENTERED IN "HARDWARE CONFIGURATION".
09	TOP DISK UNIT IS NOT INTERPRETER	CARTRIDGE MAY BE BAD. CHANGE CARTRIDGE AND PRESS RESET KEY.
0A	DISK UNIT ERROR	RETRY ENTIRE WARMSTART. TECHNICAL ASSISTANCE MAY BE REQUIRED.
0B	DISK READ ERROR	RETRY ENTIRE WARMSTART. CARTRIDGE MAY BE BAD. TRY ANOTHER CARTRIDGE.
FF	DISK SECTOR ADDRESS COMPARE INCORRECT	RETRY ENTIRE WARMSTART. TECHNICAL ASSISTANCE MAY BE REQUIRED.
xx	INDICATES ACTUAL DISK STATUS WORD (BITS 9 THROUGH 16) FOR ALL OTHER ERRORS	

DISK SYSTEM WARM START (WSTRT) ERRORS (SPO MESSAGES)

MESSAGE	MEANING	OPERATOR RESPONSE*
"ERROR 0"	HARDWARE ERROR	NO ACTION; SYSTEM MUST BE MANUALLY CLEARED.
"ERROR 1"	INVALID INPUT	"HARDWARE CONFIGURATION" PRINTED; OPERATOR MUST REENTER ALL INFORMATION.
"ERROR 2"	DISK NOT READY	SYSTEM ATTEMPTS TO RELOAD ALL CODE MODULES.
"ERROR 3"	NON-SYSTEMS PLATTER	SYSTEM ATTEMPTS TO RELOAD ALL CODE MODULES.
"ERROR 4"	DISK STATUS ERROR	SYSTEM ATTEMPTS TO RELOAD ALL CODE MODULES.
"ERROR 5"	DISK PARITY ERROR	SYSTEM ATTEMPTS TO RELOAD ALL CODE MODULES.
"ERROR 6"	DISK ADDRESS ERROR	SYSTEM ATTEMPTS TO RELOAD ALL CODE MODULES.

* ACTION TAKEN AFTER ERROR PUSHBUTTON IS PRESSED.

DISK SYSTEM RESTART ERRORS

HARDWARE-DETECTED ERRORS	
MESSAGES	
MPM PARITY ERROR	
DPM PARITY ERROR	
NPM PARITY ERROR	
DPM OVERLIMIT	
NOTE: CONSOLE HEXADECIMAL D INDICATION 80. OPERATOR SHOULD RETRY ENTIRE PROCEDURE IN RESPONSE TO EACH ERROR CONDITION.	
SOFTWARE-DETECTED ERRORS	
CONSOLE/SPO MESSAGE	OPERATOR RESPONSE
DISK NOT OPERATIONAL	READY DISK UNIT; RETRY.
NOT A SYSTEMS PLATTER	PLACE CORRECT CARTRIDGE IN DRIVE 1.
DISK PARITY ERROR	RETRY OR REPLACE CARTRIDGE.
UNWANTED DISK STATUS	READY DISK UNIT; RETRY.
NOTE: THE RESET OR ERROR KEY IS ENABLED FOR THE OPERATOR TO REQUEST A RETRY OF THE DISK ACCESS.	

DISK INITIALIZATION (MICRO-LEVEL UTILITY ERRORS)

NUMERIC ERROR MESSAGES

ERROR MSG NO.	PROBABLE CAUSE	OPERATOR RESPONSE
0000	DISK CARTRIDGE LOCKOUT	ENABLE WRITE DEVICE.
0001	DISK FILE NOT OPERATIONAL	READY DISK UNIT. CHECK CABLE CONNECTOR.
0002	DISK SEEK ERROR	PROCESSOR OR DISK UNIT MALFUNCTION REQUIRING TECHNICAL ASSISTANCE
0003	DISK TIMEOUT	FOR INITIALIZE: DEPRESS SYSTEM CLEAR, RETRY "INITD" FROM START. FOR COPY: DESTINATION DISK MAY REQUIRE INITIALIZATION. SOURCE DISK MAY BE IN ERROR. REPEATED ERRORS INDICATE NEED FOR TECHNICAL ASSISTANCE.
0004	SERVICE LATE	DEPRESS "SYSTEM CLEAR", RETRY "INITD" FROM START.
0005	ILLEGAL ADDRESS TRACK	PROCESSOR, DISK UNIT, OR PROGRAMMING ERROR. TECHNICAL ASSISTANCE REQUIRED.
0006	INITIALIZATION FAILURE (MORE THAN 50 BAD SEGMENTS OR 9 BAD AREAS)	RETRY <u>ONLY ONCE</u> WITH SAME CARTRIDGE. GENERALLY INDICATES DISK UNIT MALFUNCTION.
0009	DISK DEVICE ERROR	CAUSE NOT KNOWN, BUT 0001 IS MOST LIKELY.

DISK INITIALIZATION (MICRO-LEVEL UTILITY ERRORS) (CONT)

NARRATIVE ERROR MESSAGES (CONSOLE/SPO)

MESSAGE	MEANING
DRVE X ERR:	PREFIX TO NUMERIC ERROR MESSAGE FOR GIVEN DRIVE. (X = DRIVE NUMBER.)
COPY ERR AT	FOLLOWED BY FOUR HEX DIGIT DISK CONTROL WORD; INDICATES READ-AFTER-WRITE FAILURE IN COPY. OPERATOR MAY RETRY. DESTINATION CARTRIDGE MAY REQUIRE INITIALIZATION.
READ ERR AT	ALSO FOLLOWED BY FOUR HEX DIGITS; INDICATES PARITY ERROR ON SOURCE DISK BEING COPIED.
ADDR ERR AT	WITH HEX DIGITS, INDICATES SEGMENT ADDRESSING FOR THE TRACK SHOWN ON THE SOURCE DISK IS NOT SEQUENTIAL.
BAD SEGMENT	FOLLOWED BY FOUR HEX DIGITS, INDICATES SEGMENT FAILED READ-AFTER-WRITE CHECK DURING INITIALIZATION AND WAS DELETED FROM DISK AVAILABLE TABLES.
NOT FOR INT USE	BAD SEGMENT WAS FOUND WITHIN PROTECTED ZONE FOR INTERPRETER, HENCE THIS CARTRIDGE MUST NOT BE USED FOR INTERPRETERS.
INTERP REQUIRED	THE CARTRIDGE ON DRIVE 1 DOES NOT CONTAIN AN INTERPRETER. "INITD" WILL NOT TERMINATE TO INTERPRETER CONTROL.
ILLEGAL COPY	A REQUEST TO COPY A CARTRIDGE TO ITSELF IS ILLEGAL.
INV DRIVE	THE REQUESTED DISK DRIVE HAS NOT BEEN WARMSTARTED TO THE SYSTEM.
TRK 0 BAD - DISK UNUSABLE	BAD SEGMENT WAS FOUND IN TRACK 0 OF THIS CARTRIDGE. THE CARTRIDGE CANNOT BE USED FOR ANY PURPOSE. OPERATOR MAY WISH TO RETRY INITIALIZATION.

SYSTEM ERROR MESSAGES AND OPERATOR RECOVERY OPTIONS

SPO ERROR MESSAGE FORMAT

```

NN XXXXXXXXXXX:MMMMM
WHERE: NN IS UNIQUE TWO-DIGIT
        DECIMAL EXCEPTION CODE.
        XXXXXXXXXXX IS ABBREVIATED
        NARRATION OF EXCEPTION
        OR ERROR CONDITION.
        MMMM IS RECOVERY OPTION
        SELECTED BY OPERATOR.

```

CONSOLE ERROR MESSAGE FORMAT

```

NN XXXXXXXXXXX:M
WHERE: NN IS UNIQUE TWO-DIGIT
        DECIMAL EXCEPTION CODE.
        XXXXXXXXXXX IS ABBREVIATED
        NARRATION OF EXCEPTION
        CONDITION.
        M IS RECOVERY OPTION
        SELECTED BY OPERATOR.

```

OPERATOR RECOVERY RESPONSES

```

A - RETRY INITIATE. (* FOR PARITY ERROR, RELOAD CARD READER AND RETRY INITIATE.)
B - ENABLES KEYBOARD TO ALLOW OPERATOR ENTRY OF FIVE-CHARACTER ALTERNATE FILE NAME.
C - ENTER NEW DEVICE NUMBER.
D - PURGE OLD FILE OR TAPE CASSETTE.
E - TERMINATE JOB.
F - END OF FILE.
G - IGNORE ERROR AND PROCESS.
H - DO NOT PUT OBJECT PROGRAM ON DISK.
I - LOAD CONTINUATION TAPE CASSETTE AND RETRY INITIATE.
J - GO TO READY MODE.

```

SYSTEM ERROR MESSAGES AND OPERATOR RECOVERY RESPONSES

ERROR MESSAGE	SPO ENTRY CONS. KEY	OPERATOR RESPONSE (PAGE 49)			
		SKID1	SKID2	SKID3	SKID4
		SHIFT 1	SHIFT 2	SHIFT 3	SHIFT 4
01 CR1 NOT RDY:		A*			F
02 CR2 NOT RDY:		A*			F
10 PT1 NOT RDY:		A			E
11 PT2 NOT RDY:		A			E
12 PT1 PAR ERR:		A	A	A	E
13 PT2 PAR ERR:		A	A	A	E
20 LP PAR ERR:		A	A		
21 LP NOT RDY:		A			
40 Cnn READ ERR:		A			E
41 Cnn PCH ERR:		A	G		
42 Cnn HOP EMP:		A			E
43 Cnn NOT RDY:		A*			
Cnn = 96-1,96-2,80-1, OR 80-2.					
DISK					
50 DSK SEEK ER:		A			E
51 DSK READ ER:		A	G		E
52 DSK WRIT ER:		A	G		E
53 DSK ADD ERR:		A			E
54 DSK DEV ERR:		A			E
55 N-F XXXXX:		A	B	C	E
56 D-F XXXXX:		A	B	D	H
57 NO USER DSK:		A		C	E
58 DSK INV KEY:		J	J	J	J
59 DKn NOT RDY:		A		C	
61 O-C XXXXX:		J		J	J
62 RT LENGTH:		J	J	J	J
CASSETTE AND MAGNETIC TAPE					
70 N-F XXXXX:		A	G	B	A
71 TPn NOT PRG:	n=UNIT NO.	A	A	D	A
72 TPn TP REQD:		I	I	I	I
73 TPn REC LEN:		A	G		E
74 TPn LOCKED:		A			
75 TPn TP ERR:		A	G		E
76 TPn NOT RDY:		A	G		E
77 O-C XXXXX:		J	J	J	J
79 TPn OP REQD: TAPE ON CLEAR LEADER		A	A	G	A
80 TPn NO TM:		J	J	J	J
83 TPn REC ERR:		J	J	J	J
84 TPn BLK ERR: XXXXX REEL #NNN REQD. XXXXX IS FILE NAME. NNN IS REEL NO.		A	A	A	E

UTILITY PROGRAM EXCEPTION CONDITION MESSAGES
AND RECOVERY OPTIONS

EXCEPTION CONDITION (MESSAGE)	ATTEMPT RECOVERY USING SHIFTED NUMERIC KEY(S)				EXCEPTION CONDITION (MESSAGE)	ATTEMPT RECOVERY USING SHIFTED NUMERIC KEY(S)			
	1	2	3	4		1	2	3	4
01 CR1 NOT RDY:	A*				54 DSK DEV ERR:	A			
02 CR2 PAR ERR:	A*	C			55 N:F XXXXX:	A	D	E	G
10 PT1 NOT RDY:	A				56 D:F XXXXX:	A	D	F	G
11 PT2 NOT RDY:	A				57 NO USER DSK:	A	D	F	G
14 PPI NOT RDY:	A				70 N-F XXXXX:	NOT APPLICABLE			
15 PPI NOT RDY:	A				71 TPn NOT PRG:	NOT APPLICABLE			
16 PPI ECHO CK:	A				72 TPn TP REQD:	A**			
17 PP2 ECHO CK:					73 TPn REC ER:	NOT APPLICABLE			
20 LP PAR ERR:	A	C			74 TPn LOCKED:	A	A	C	G
21 LP NOT RDY:	A				75 TPn TP ERR:	A	C		G
40 C96 NOT RDY:	A*				76 TPn NOT RDY:	NOT APPLICABLE			
50 DSK SEEK ER:	A				79 TPn OP RQD:	A**			
51 DSK READ ER:	A				81 TPn INV CONT:	A	C		G
52 DSK WRIT ER:	A				82 TPn NO BOF:XXXXX:	A	C		G
53 DSK ADD ERR:	A				84 TPn REC ERR:	I	J		G

KEY FUNCTIONS

- A - RETRY INITIATE. *FOR PARITY ERROR,
RELOAD CARD READER AND RETRY
INITIATE. **LOAD CONTINUATION TAPE
AND RETRY INITIATE.
- B - END OF FILE, NORMAL TERMINATION FOR
BC180, BC196, 18096, AND 08096
PROGRAMS.
- C - IGNORE ERROR AND PROCESS.
- D - ENABLES KEYBOARD TO ALLOW OPERATOR
ENTRY OF 5-CHARACTER ALTERNATE
FILE NAME.
- E - ENTER NEW DEVICE NUMBER
- F - PURGE OLD FILE.
- G - TERMINATE PROGRAM.
- H - PURGE THE TAPE.
- I - USE THE NUMBER OF TAPE RECORDS
ACTUALLY READ TO COMPUTE THE
NUMBER OF DISK RECORDS.
- J - USE THE NUMBER OF TAPE RECORDS
SPECIFIED THROUGH THE KEYBOARD
TO COMPUTE THE NUMBER OF DISK
RECORDS.

OPERATING SYSTEM ERRORS (FATAL)

DISPLAY FORMAT EXAMPLE

**D368	INVALID-I/O	0 0657 2	0 00106AFD	FFFF 0000 0020 0032
SPO REPRESENTATION OF CONSOLE INDICATORS (SPO SYSTEM ONLY)	ERROR MESSAGE (REASON FOR ERROR)	PROGRAM LOCATION OF NEXT S-LEVEL INSTRUCTION	PARA. OF INSTRUCTION REGISTER	I/O RESULT (I/O ERRORS ONLY)

SPO REPRESENTATION (DISPLAY) OF CONSOLE INDICATORS

**ABCDS12345678	
WHERE: ** IS CONSTANT DENOTING DISPLAY FUNCTION.	
A, B, C, D, AND S DENOTE INDICATOR BANK(S), WHERE:	
A	= PK1-PK8
B	= PK9-PK16
C	= PK17-PK24
D	= UNNUMBERED BANK
S	= R, A, N, OR E FOR READY, ALPHA, NUMERIC, AND ERROR, RESPECTIVELY.
1 THROUGH 8 REPRESENT INDICATORS OF DENOTED BANK(S) (A1-A8, B1-B8, ETC.)	
EXAMPLES:	**D18 (FIRST AND LAST ERROR INDICATORS LIT)
	**C6 (PK22 LIT)
	**AB34 (PK3, PK4, PK11, AND PK12 LIT)
	**SA (ALPHA LIT)
	**SR (READY LIT)

OPERATING SYSTEM ERRORS (FATAL) (CONT)

HARDWARE ERRORS

HEX "D" IND. PATTERN	ERROR MESSAGE	DESCRIPTION
80	(NO ERROR MSG)	HARDWARE DETECTED PARITY ERROR IN PAPER TAPE DATA DURING READ-IN OF DATA FROM CONSOLE MEMORY LOADER TO MPM.
81	MPM - PARITY	HARDWARE DETECTED PARITY ERROR IN MPM PORTION OF SHARED MEMORY WHILE ATTEMPTING TO ACCESS A MICROINSTRUCTION, OR PARITY ERROR WAS DETECTED IN MPM READ-AFTER-WRITE CHECK DURING LOADING FROM CONSOLE PAPER TAPE READER.
82	DPM - PARITY	HARDWARE DETECTED PARITY ERROR IN DPM PORTION OF SHARED MEMORY WHILE ATTEMPTING TO READ OR WRITE DATA MEMORY.
83	NPM - PARITY	HARDWARE DETECTED PARITY ERROR IN AN NPM WORD WHILE ATTEMPTING TO READ A NANO-INSTRUCTION.
84	DPM - OVER - LIMIT	HARDWARE DETECTED MEMORY ADDRESS IN EXCESS OF THE MEMORY.
92	SPM - LIMIT	INTERPRETER DETECTED AN ATTEMPT TO WRITE OUTSIDE SPM AREA DEFINED FOR THIS PROGRAM.
93	DPM - UNDER - LIMIT	INTERPRETER DETECTED A WRAP-AROUND (THROUGH INDEXING) OF DATA MEMORY.
94	POSITION	CARRIER STALL DETECTED WHILE POSITIONING; CARRIER OVERSPEED DETECTED WHILE PRINTING; OR INTERPRETER DETECTED AN ATTEMPT TO POSITION CARRIER BEYOND LIMIT IMPOSED BY PLATEN SIZE VALUE OF KEYBOARD DATA SEGMENT CURRENTLY IN USE BY INTERPRETER.
95	INVALID - INST	INTERPRETER DETECTED AN INVALID OP CODE OR AN INVALID OPTION ON A VALID OP CODE.

OPERATING SYSTEM ERRORS (FATAL) (CONT)

HARDWARE ERRORS (CONT)

HEX "D" IND. PATTERN	ERROR MESSAGE	DESCRIPTION
A2	ILLEGAL - I/O	INTERPRETER DETECTED AN ILLEGAL REQUEST TO I/O DEVICE.
A3	BUFFER - LIMIT	INTERPRETER DETECTED ONE OF THE FOLLOWING ON AN "INITIATE" OR "CALL" OPERATION: A. STARTING BUFFER ADDRESS > BUFFER SIZE. B. NUMBER OF WORDS > BUFFER SIZE. C. (A) + (B) > BUFFER SIZE.
A4	INVALID - I/O	ATTEMPT WAS MADE TO ACCESS DEVICE NOT WARM-STARTED TO SYSTEM, OR A BUFFER OR SUB-SYSTEM NOT DEFINED FOR THIS PROGRAM.
A5	I/O - INCOMPLETE	ATTEMPT TO ACCESS A VALID DEVICE HAS "TIMED-OUT" DUE TO AN ERROR, AN AMBIGUOUS RESPONSE, OR NO RESPONSE FROM THIS DEVICE.

RJE BOOTSTRAP LOAD ERROR MESSAGES (NON-DISK SYSTEM WITH SPO)

SPO MSG	CAUSE
PAR	THE GENERATED LPC DOES NOT AGREE WITH THE LRC ON THE CARD. THE MOST PROBABLE CAUSE IS THAT AN UNIDENTIFIED CARD CAUSED THE LRC CHECK.
?ST	A STATUS .CONDITION OCCURRED DURING THE LOAD PROCESS. THE CAUSE MAY BE: 1. INVALID MULTI-PUNCH COLUMN. 2. READ CHECK. 3. FEED CHECK.
CNT	THE WORD COUNT ON THE LAST CARD READ IS INCORRECT.
ILL	A NON-DECIMAL CHARACTER WAS DETECTED (POSSIBLY CAUSED BY MISPLACED FIELDS).

C8

B043 CONSOLE IOC/DDP WORD FORMATS

MSB	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	LSB	
CONTROL WORD	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
KB DATA WORD	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
PRINTER DATA WORD	0	1	-	-	ESCAPE RIGHT	ESCAPE LEFT	RED RIBBON	PRINT	-	KB8	KB4	KB2	KB1	KB8	KB4	KB2	KB1
INDICATOR DATA WORD	1	0	-	IND BNK A	IND BNK B	IND BNK C	IND BNK D	IND BNK S	-	-	-	-	-	-	-	-	-
CARRIER DATA WORD	0	0	-	-	-	-	INIT.	LEFT	128	64	32	16	8	4	2	1	-
FORMS DATA WORD	1	1	-	-	-	-	-	-	-	LEFT PLAT ADV.	RIGHT PLAT ADV.	-	-	-	-	-	-
STATUS WORD	-	-	-	16	8	4	2	1	-	-	-	-	-	-	-	-	-

LIT

B044 SPO IOC/DDP WORD FORMATS

MSB	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	LSB
CONTROL WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
DATA WORD	---	---	---	---	---	---	---	---	DATA	DATA	DATA	DATA	DATA	DATA	DATA	DATA	DATA
STATUS WORD	---	---	---	DEV ADDR	DEV ADDR	DEV ADDR	DEV ADDR	DEV ADDR	---	---	---	SERVICE TOO LATE	ERROR	END OF MSG	INPUT REQ	NOT READY	---

NOTE: DEVICE ADDRESS BITS OF STATUS WORD ARE INSERTED AT THE PSU.

B0111 CARD READER IOC/DDP WORD FORMATS

MSB	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	LSB
CONTROL WORD	0												0	DEV. OR CLR.	PICK TERM		
DATA WORD	0							0	CC12	CC11	CC10	CC9	CC8	OCT4	OCT2	OCT1	
STATUS WORD	DR	0	0	DA	DA	DA	DA	DA	0	0	0	SFEC	SLECC	TRBL	NO FEED	RDY	

WHERE:
 0 = NOT USED
 ∅ = NOT APPLICABLE
 DA IS GENERATED BY PSU.

B0115 CARD READER IOC/DDP WORD FORMATS

MSB	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	LSB
CONTROL WORD	---	---	---	---	---	---	---	---	---	---	---	ENABLE INTER	READ BIN	CLEAR	READ NORM	TERM	
DATA WORD, NORMAL	CON-TROL CHECK								DATA 7	DATA 6	DATA 5	DATA 4	DATA 3	DATA 2	DATA 1	DATA 0	
DATA WORD, BINARY	---	---	---	---	---	---	---	---	DATA 11	DATA 10	DATA 9	DATA 8	DATA 7	DATA 6	DATA 5	DATA 4	
STATUS WORD	DATA REQ	---	---	DEV ADDR 4	DEV ADDR 3	DEV ADDR 2	DEV ADDR 1	DEV ADDR 0	---	---	---	---	---	TROU-BLE	---	RDY	

NOTE: DEVICE ADDRESS BITS OF STATUS WORD ARE INSERTED AT PSU.

B0121-1 PPT/EPC READER IOC/DDP WORD FORMATS

MSB	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	LSB
CONTROL WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	OPEN CLAMP	READ	
DATA WORD	---	---	---	---	---	---	---	---	DATA 7	DATA 6	DATA 5	DATA 4	DATA 3	DATA 2	DATA 1	DATA 0	
STATUS WORD	DATA	---	DEV ADDR 4	DEV ADDR 3	DEV ADDR 2	DEV ADDR 1	DEV ADDR 0	---	---	---	---	---	---	---	SERVICE TOO LATE	DEV NOT RDY	

NOTE: DEVICE ADDRESS BITS OF STATUS WORD ARE INSERTED AT PSU.

B0221 PPT/EPC PUNCH IOC/DDP WORD FORMATS

MSB	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	LSB
CONTROL WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	PUNCH	
DATA WORD	---	---	---	---	---	---	---	---	DATA 7	DATA 6	DATA 5	DATA 4	DATA 3	DATA 2	DATA 1	DATA 0	
STATUS WORD	DATA REQ	---	---	DEV ADDR 4	DEV ADDR 3	DEV ADDR 2	DEV ADDR 1	DEV ADDR 0	---	---	---	ECHO CHECK	TAPE LOW	PUNCH OFF	MEDIA NOT PRESENT	NOT READY	

NOTE: DEVICE ADDRESS BITS OF STATUS WORD ARE INSERTED AT PSU.

B0392 TAPE CASSETTE IOC/DDP WORD FORMATS

MSB																LSB
CONTROL WORD	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
DATA WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
STATUS WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
DATA REQ	---	---	---	DEV ADDR 4	DEV ADDR 3	DEV ADDR 2	DEV ADDR 1	DEV ADDR 0	5 MSEC TIME MARK	DATA 7	SERV TOO LATE	RE-CORD GAP	END OF TAPE	FILE PROT	TAPE ERROR	DEVICE NOT READY

NOTE: DEVICE ADDRESS BITS OF STATUS WORD ARE INSERTED AT PSU.

B0418-2 READER-PUNCH-RECORDER IOC/DDP WORD FORMATS

MSB																LSB
CONTROL WORD	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
DATA WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
STATUS WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
DATA REQ	---	OPER REQUEST	DISABLE STATUS	CLEAR TERM	STKR SEL 4	STKR SEL 2	STKR SEL 1	SEP PRINT	INHIBIT INPUT FEED	PRINT	PUNCH	SECOND FEED SELECT	SELECT SECOND PATH	LOAD OUTPUT BUF	UNLOAD INPUT BUF	START CARD CYCLE

NOTE: DEVICE ADDRESS BITS OF STATUS WORD ARE INSERTED AT PSU.

96 COL. 6 BITS
80 COL. 12 BITS BIT 16-5


B0489 DISK IOC/DDP WORD FORMATS

MSB																LSB
CONTROL WORD	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
DATA WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
STATUS WORD	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---
DATA REQ	---	DRIVE SEL	TRACK 8	TRACK 7	TRACK 6	TRACK 5	TRACK 4	TRACK 3	TRACK 2	TRACK 1	TRACK 0	FACE	TERM	OPER 2	OPER 1	OPER 0


NOTE: DEVICE ADDRESS BITS OF STATUS WORD ARE INSERTED AT PSU.

OPERATION	OP2	OP1	OP0
NO OP	0	0	0
SEEK	0	0	1
READ NEXT SECT	0	1	1
NOT ALLOWED	0	1	0
WRT NEXT SECT	1	0	1
ENABLE MRS	1	0	1
LOC & VERIFY	1	1	0
NOT ALLOWED	1	1	1


SL7 I/O DESCRIPTOR FORMAT



DISK CARTRIDGE DRIVE FUNCTIONAL DESCRIPTORS




LINE PRINTER FUNCTIONAL DESCRIPTORS



AAAAAA = 000000 NO SPACE

- 000001 SINGLE SPACE
- 000010 DOUBLE SPACE
- 001000 VARIABLE SKIP (CHANNEL 1)
- 110000 BOTTOM OF FORM (CHANNEL 2)
- 000100 TOP OF FORM (CHANNEL 3)
- 100000 VARIABLE SKIP (CHANNEL 4)


RESULT DESCRIPTOR



F = 1 FORMAT ONLY
 F = 0 PRINT THEN FORMAT
 SUBSYSTEM = 4
 DEVICE PORT = 2

- A = NOT READY
- B = END OF PAGE
- C = DEVICE ERROR (PARITY)
- S = STANDARD

TAPE CASSETTE FUNCTIONAL DESCRIPTORS




CC . . . C = 0-255
 WHERE 0 → 1 CHAR

FFFF = 0000 READ

- 0001 WRITE
- 0010 REWIND
- 0011 ERASE
- 0100 BACKSPACE
- 0101 WRITE TAPE MARK
- 0110 SEARCH FORWARD
- 0111 SEARCH REVERSE (CASS. ONLY)
- 1000 REWIND/INHIBIT (CASS. ONLY)

RESULT DESCRIPTOR



SUBSYSTEM = 3
 DEVICE PORTS = 0-3

- A = RECORD LENGTH INCORRECT
- B = TAPE MARK
- C = END OF TAPE
- D = FILE PROTECT
- E = TAPE ERROR
- F = NOT READY
- G = OPERATOR INTERVENTION
- S = STANDARD

MIR - *
INCR - $\downarrow\uparrow$
MPM - $\uparrow\downarrow$
FEAC - $\downarrow\uparrow$

C800^A
9059
F000

Wherever There's
Business There's



Burroughs

Printed in U.S.America

REVISED 5-1-74

1059/55